

ROLY

BEYOND ENVISION

RS232 Commend

1. Connection	
1.1 Port Setting	
Method	Asynchronous communication
波特率	19200
Data bits	8
Parity	none
Stop bits	1
Flow control	none
1.2 Wiring	
Connect the computer and projector with RS232 直通	
2. Command List	
Command (HEX+CR)	Function
C00(43 30 30 0D)	POWER ON
C01(43 30 31 0D)	POWER OFF(Power OFF immediately)
C20(43 32 30 0D)	Input VGA
C22(43 32 32 0D)	Input HD BASE
C23(43 32 33 0D)	Input HDMI
C24(43 32 34 0D)	Input DVI
C25(43 32 35 0D)	Input VIDEO
C26(43 32 36 0D)	Input Medis